

## Warranty

This product is covered by 6-month warranty when purchased from [www.anobik.com](http://www.anobik.com) or an authorized reseller. The warranty covers functional abnormalities under normal use during the warranty period. For more information, contact your local ANOBIK dealer or visit: [www.anobik.com/warranty](http://www.anobik.com/warranty)

Warranty will be void if damaged by wear and tear, abnormal stress on wire, burn, soaked by liquid etc.

### Warranty Information


Product Name/ Model No.	Fusion I In-Ear Headphones
Product Serial Number	
Date of Purchase	
Dealer Name	
Authorized Seal and Signature	

## Contact Us

Anobik Technologies Limited | Dhaka, Bangladesh  
+88017 88 99 80 80  
[support@anobik.com](mailto:support@anobik.com)



# ANOBIK



Fusion  
In-Ear Headphones  
USER MANUAL

## Specifications

Speaker size	8mm
Frequency range	20-20000Hz
Sensitivity	104±3dB
Impedance	16Ω
Cable length	120cm
Jack Type	3.5mm



## Important Safety Information

To avoid hearing damage, make sure that the volume on your music player is turned down before connecting your headphones. After placing headphones in your ears, gradually turn up the volume until you reach a comfortable listening level.

Do not use headphones when it's unsafe to do so—while operating a vehicle, crossing streets, or during any activity or in an environment where your full attention to your surroundings is required.

## How to use

Fusion is an In-Ear Headphones and relies on a tight seal between the earbuds and your ear canals to deliver good bass response and overall sound quality. Three sizes (S/M/L) of silicone earbuds are included to help you achieve the best fit. We recommend trying all of included earbuds and selecting the ones that provide the best sound and comfort for your ears.

To put on the headphones, first identify the left and right earpieces as indicated by the "L" and "R" markings. They are not interchangeable.

## Multi-function button

Function	Operation
Play/Pause Music	Short press the button once
Previous track	Continuous short press the button 3 times
Next track	Continuous short press the button 2 times
Answer/end call	Short press the button once during call
Reject call	Press and hold (1 sec) the button during call

