
ANOBIK

10000mAh Dual Port Power Bank

Essential 10000 Slim Model: E1020



Check Remaining Capacity

• Press the Power Button and the LEDs will light to show remaining capacity

Power Indicator	•000	••00	$\bullet \bullet \bullet \circ$	
Battery Status	≤25%	25% ~ 50%	50% ~ 75%	75% ~ 100%

Charge your phone or tablet

 Connect your phone or other portable device to the Power Bank using included USB cable or your original USB charger cable.

 The Power Bank will start charging your device automatically and stop once either your device is fully charged or the power bank is discharged.

Recharge your Power Bank

- Connect your Power Bank to your USB charger using included USB cable or your phone's original cable.
- During charging the LEDs will flash to show charging status.
- When charging is complete all four LED's will be permanently on.

(- To preserve battery lifespan, use and recharge the Power Bank at least once every 4 months.

F To give your Power Bank fastest, safest recharge, use an ANOBIK USB harger







Capacity	10000mAh (37Wh)	
Battery Type	Lithium Polymer	
Micro USB Input	5V 2A	
USB-C Input	5V 2A	
USB Output 1/2	5V 2A	
Charge Cycle	>500 times	
Size	135.5 x 67 x 15 mm	
Weight	217 g	

Important Safety Information

- Avoid extreme temperatures
- ΨN
- Use original or certified cables



Do not expose to liquids





Avoid dropping

Wipe surfaces with a damp cloth and dry with a clean dry cloth tin



The 6-Month Replacement Warranty for Quality-Related Issues applies to physical products purchased from anobik.com or an authorized reseller. The warranty covers functional abnormalities under normal use during the warranty period.

ssential 10000 Slim

Contact Us

Anobik Technologies Limited | Dhaka, Bangladesh support@anobik.com www.fb.com/anobiktech

